

INSTALLATION INSTRUCTIONS Norm Aluminium roll



Placing - unrolling - pressing down

Place the central part of roll to ridge lath, align and fasten (tacker on, for instance).



Align to roof tiles on each side and adjust



Metre after metre, remove separating film on roll sides.



Press butyl adhesive strip on tile (wave - wave - hollow).



Important note: The adhesion immediately starts, therefore not allowing any later corrections.

INTER DACH NORM
Scheffler GmbH & Co. KG

Bahnhofstraße 40
59597 Erwitte

Tel.: +49 (0) 2943 - 9759834
Fax +49 (0) 2943 - 9759831