

Installation Information

Aluminium Roll

Apply – roll out – press on

Place middle part of the roll on the roof ridge batten, adjust and fix (e.g. stapling)



Apply to the roof tiles on either side and adjust to fit.
(Valley [strike out] – wave – valley)



Remove separating film from the sides of the rolls gradually.



Press butyl adhesive tape firmly to the tiles.



Attention:

The gluing process sets in immediately; therefore it is not possible to make corrections later.

If the butyl adhesive tape is not properly pressed on, it may collect dust or dirt, which causes it to lose its adhesive properties, e.g. cutting caused by burrs.